



Congratulations! You are just moments away from making your Shabbat even more pleasurable than it already is. No more worrying about being late for *minyan* or missing your afternoon *chavrusah*. No need to ask someone to wake you. Just follow the simple instructions and you'll soon be waking up *Shabbos* morning in time for minyan... and the alarms shut off by themselves!

KosherClock Features

1. Display time/alarm.
2. Set five different alarm times
3. Digital recording of a 10 second message.
4. Choose your alarm sound; classic beep or pre-recorded message
5. Select 12 or 24 hour format
6. Countdown timer -- Maximum 23 hour 59 minutes
7. Holds a 2.2" X 3.4" photo



Operating your KosherClock

NOTE: All setting of times and alarms must be done prior to Shabbat. You may not touch any buttons on Shabbat.

Modes:

By pressing the MODE key, you can cycle through the different screens:

Normal Display State	press MODE once and the display advances to → Alarm 1
Set Alarm 1 time	press MODE once and the display advances to → Alarm 2
Set Alarm 2 time	press MODE once and the display advances to → Alarm 3
Set Alarm 3 time	press MODE once and the display advances to → Alarm 4
Set Alarm 4 time	press MODE once and the display advances to → Alarm 5
Set Alarm 5 time	press MODE once and the display advances to → Countdown Timer
Set Countdown timer	press MODE once and the display advances back to → Normal Display

What is the “Normal Display State”?

This is what it looks like when the time is being shown. You will see two flashing dots between the hour and the minutes. The KosherClock always returns to the Normal Display State after being inactive for 60 seconds.

Setting the current time of your KosherClock

From the Normal Display State, press and hold MODE for 2 seconds until the digits flash to begin setting the current time. Then press HOUR to adjust the hour and press MIN to adjust minutes. By holding down the HOUR or MIN key, the digits will advance rapidly. When the time is correct, press MODE again to confirm the setting. If you do not touch any button for 1 minute, the LCD will stop flashing and automatically set the time.

Setting the Display Time Format (12 hour, or 24 hour)

Press HOUR under Normal Display State to switch between 12 or 24 hour format. To test whether you are showing 24 or 12 hour time, a little “P” will display when pressing HOUR in the afternoon.

Setting the Alarms on your KosherClock

To get to Alarm 1, press MODE once from the Normal Display and your KosherClock will enter “set Alarm 1 time” mode.

To set, press and hold MODE for 2 seconds until the digits flash, then press HOUR to adjust the hour and press MIN to adjust minutes. By holding down the HOUR or MIN key, the digits will advance rapidly. When the alarm time is correct, press MODE again to confirm the setting.

If the alarm is set, the LCD will display the time with a numbered alarm bell like this:



To deactivate the alarm, while in the set alarm MODE:

Press and hold the MIN key.

If alarm has been cleared, the LCD will display as:



To set Alarm 2, press MODE two times from normal display, and repeat steps as for Alarm 1.

To set Alarm 3, press MODE three times from normal display, and repeat steps as for Alarm 1.

To set Alarm 4, press MODE four times from normal display, and repeat steps as for Alarm 1.

To set Alarm 5, press MODE five times from normal display, and repeat steps as for Alarm 1.

Setting the Countdown timer on your KosherClock

To get to the countdown timer, press MODE six times from Normal Display State, and your KosherClock will enter “Set Countdown Timer” mode. To set, repeat steps as for Alarm 1. If the countdown Alarm is set, the LCD will display like this:



Press MIN to start or pause the countdown alarm.

When the countdown time is expired, the alarm will ring.

(NOTE: DO NOT USE COUNTDOWN TIMER ON SHABBAT)

Setting the Alarm Ringing Options

Slide the switch to BEEP position indicated by the  and when any of the Alarms go off, a “beeping” sound will be heard for 60 seconds and stop. Slide the switch to the MSG position, and when any of the Alarms go off, your pre-recorded message will play for 60 seconds and stop. Slide the switch to MUTE position, and even when the alarm is on, the alarm will be muted. This is convenient if you want to keep the same alarms for each Shabbos and not want to hear them during the week. Just before the next Shabbos, slide the switch to BEEP/MSG, and your Alarms will still be there from the previous week.

Recording your Message

Your KosherClock comes with a pre-recorded melody that you may use as your Alarm. If you choose, you may record a message via the built-in microphone. Slide the switch to MSG position. Press and hold down the REC button for recording your 10 second message. Hold down the REC button the whole time you are recording. Press PLAY to play back what you recorded. **NOTE:** pressing REC will erase the previously recorded message.

Maintenance

Use 2 alkaline batteries, size AAA. Please replace the batteries when sound is distorted during playback or when display is unclear. Open the battery compartment at the bottom of the KosherClock to replace the battery. **NOTE:** it is important to install the batteries correctly—otherwise the alarms may not sound, even if the time still displays.

